



## MAGNAGLO® 14A FLUORESCENT MAGNETIC POWDER

### GENERAL DESCRIPTION

Magnaglo® 14A is a dry, free flowing, brown magnetic powder which fluoresces bright yellow-green under black light (wavelength of 365 nanometers). 14A is intended for use in high sensitivity wet method magnetic particle inspection and may be suspended in either a petroleum-based vehicle (oil) such as Magnaflux®/Magnaglo® Carrier II, or in water. When water is used as a vehicle, conditioning agents such as WA-2B, or WC-1 are required. The conditioning agents improve particle suspendibility and mobility, part surface wetting, and nominal corrosion inhibition. 14A's fluorescent color contrasts sharply with the purple background of clean metal surfaces when viewed under black light in a darkened area.

### APPLICATIONS

Magnaglo® 14A is used to locate fine surface and slightly subsurface discontinuities such as: inclusions, seams, shrink cracks, tears, laps, flakes, welding defects, grinding cracks, quenching cracks, and fatigue cracks.

### COMPOSITION

Magnaglo® 14A is composed of compounded fluorescent pigment and magnetic powder.

### TYPICAL PROPERTIES (Not a specification)

Typical Properties	14A
Color Under White Light	Brown
Color Under Black Light	Yellow-Green Fluorescence
Mean Particle Size	6 Microns
SAE Sensitivity	8 - 9
Temperature Limit	120°F Maximum

*Note! A measuring scoop is included with each 14A container. The scoop measures enough 14A particles for one gallon of Carrier II or water.*

### BATH PREPARATION

**Oil Bath:** When Carrier II is used as the vehicle, the 14A is weighed out (1/6 oz. per gallon of Carrier II) and added to the Carrier II. The bath must be agitated for several minutes to distribute the particles uniformly. Once thoroughly mixed, the bath should be checked for proper concentration and adjusted if necessary.

**Water Bath:** When water is used as the vehicle, the conditioning agent is measured out, added to the agitated bath, and allowed to mix for several minutes. Once mixed, the 14A is weighed out (1/6 oz. per gallon vehicle) and added to the bath, and again allowed to be mixed uniformly. The bath is tested for proper concentration and adjusted if necessary.

## CONCENTRATION CONTROL

The bath strength should be maintained constant at all times to provide consistent results. The concentration should be checked at make-up time and at least once each day. The most widely used method of control is by gravity settling in a graduated ASTM pear shaped centrifuge tube. Magnaflux® part number 8493 is recommended for 14A with a 1.0 ml stem in 0.05 increments. The centrifuge tube is filled to the 100 ml line with well mixed bath and placed in the stand in a vibration-free location for 30 minutes for water baths, or 60 minutes for oil baths. After the 30 minute wait for water or the 60 minute wait for Carrier II, the settling volume is taken. The settling volume indicates the amount of magnetic particles present in the bath.

Product	Typical Settling Oil	Typical Settling Water
14A Concentration 1/6 oz/gal (1.25 g/l)	0.15 - 0.25	0.18 - 0.28

## METHOD OF APPLICATION

Parts should be cleaned prior to testing to reduce bath contamination and to ensure a more desirable test surface. The bath must be continuously agitated when in use to ensure uniformity, as particles will settle out of suspension on standing. Using the wet continuous method, the bath is applied to all surfaces of the part. The instant the bath stream is removed from the part the magnetizing current is applied. The indications will be formed during the current shot. If the bath is applied after the magnetizing shot, the force of the bath application may wash away indications.

Using the wet residual method, the pre-magnetized part (must be of high retentivity) is immersed in the bath and then removed and allowed to drain. The indications will be formed in the bath but background will be reduced during the drain. This method is generally less sensitive than the continuous method. The bath is also more susceptible to rapid particle depletion and contamination using this method.

## POST INSPECTION CLEANING

The parts must be properly demagnetized before cleaning to ensure ease of particle removal.

**SPECIFICATION COMPLIANCE:** ASTM E 1444, ASME B & PV Code, Sec. V, NAVSEA 250-1500-1, ASTM E-709 (E-138), MIL-STD-271, AMS-3044, Cummins IS-16048-13, MIL-STD-2132; Boeing PS 21201, British Std. B.S. 4069.

## PACKAGING

1 Lb. Plastic Jar, 6-Pack of 1 Lb. Plastic Jars, 20 Lb. Plastic Pail.

*Please also refer to the Product Data Sheet for 14AM, 14A Aqua-Glo, 14A Redi-Bath, and 20B Fluorescent Magnetic Particle Prepared Bath.*

DISTRIBUÉ PAR / DISTRIBUTED BY:



QUEBEC  
164, St-Jean-Baptiste  
Mercier, QC J6R 2C2  
T : (450) 691-9090

ONTARIO  
275 Sheldon Drive, Unit 3  
Cambridge, ON N1T 1A3  
T : (519) 894-9069

[www.qnde.ca](http://www.qnde.ca)